
nylex



Wall Mountable Hose Reel

Instruction Manual




Caution




- Before use and installation of this product, ensure you read the entire manual.
- This hose reel is designed for residential watering applications only. It is not intended for commercial applications.
- If operating from the wall mount, ensure the Hose Reel is securely attached to the wall.
- Regularly inspect the bracket for signs of wear.
- Avoid exceeding the recommended length capacity of the Hose Reel.

What you will need



Included Parts




Warning



- Ensure there are no live electrical wires or plumbing in the wall at the location you are drilling.
- If your wall's plywood cladding is thicker than 12mm you can directly mount the wall bracket to this wall.
- Ensure the wall or surface you install the reel on can support the weight of the hose when fully loaded.


Installation



Step 1

Choose the location: It is recommended to install the wall bracket on a flat surface located near a tap if intended to use mounted.


Mark the position: Using a level and the bracket template (E) provided, mark the position of the holes on your chosen surface.



Step 2


Install the bracket: Line up wall bracket (A) and (B) as pictured and secure using wall fixings (D) provided.

Secure wall brackets (C) at the marked points with remaining wall fixings (D).




Step 4

Attaching the reel: Ensure both wall bracket tabs are fully rotated inwards. Line up the reel to the brackets and push down to fit in holder. Push wall bracket mount tabs over the metal tube to secure the reel.




Drill holes at the marked points and insert the wall plugs (D) if required.

Nylexpert Tip: Installing the hose hanger in a position out of direct sunlight and elements will help extend the hose life.



Step 3

Handle assembly: Unscrew the cap on the side of the reel and align the handle (H) opening to the thread. Thread the cap back onto the side of the reel.



Step 5

Connect to water source: Connect the reel to your water source using the tap to reel hose (G) and tap adapter (F) provided.

Care

- Always turn the water off at the tap when the hose reel is not in use.
- Do not place undue force on the hose reel. Doing so may damage the reel or the bracket.
- To prevent freezing and potential damage to the hose reel, store indoors during winter months.
- Clean the housing and hose using only mild soap and water.

Warranty

AMES Australasia Pty Ltd (AMES) guarantees that this product will be free from defects in workmanship and materials for 5 years from the date of purchase. If such a defect becomes evident during that period, AMES will, at its option, either repair, replace or refund the product. In the event of such a defect, the product should be returned to the place of purchase (together with proof of purchase and the original packaging) at the address below. Any handling and transportation costs (and other expenses incurred in claiming under this guarantee) are not covered by this guarantee and will not be borne by AMES. The obligation of AMES under this guarantee is limited to the circumstances set out above and is subject to; the customer being able to evidence the acquisition of the product, the purchase price paid for the product and the relevant defect in materials or workmanship; the product not having been altered, tampered with or otherwise dealt with by any person in a manner other than as intended in respect of the relevant product; and the product not having been used or applied in a manner that is contrary to customary usage or application for the relevant product or contrary to any stated instructions or specifications of AMES. In addition to other rights and remedies that may be available under law, our goods come with guarantees that cannot be excluded under the Australian Consumer Law (for consumers in Australia) and the Consumer Guarantees Act (for consumers in NZ). If you are a consumer in Australia, you are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. If you are a consumer in New Zealand, we will comply with our obligations to you under the Consumer Guarantees Act.

For further information contact us on

Email: nylex@amesau.com Australia Free Call: 1300 381 559 New Zealand: 0800 447 144

AMES Australasia

ABN 89 169 427 061 Level 1, 660 Doncaster Road, Doncaster, Victoria, 3108, Australia.





Scan for user guide